myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for PIONEER DV-355. You'll find the answers to all your questions on the PIONEER DV-355 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual PIONEER DV-355
User guide PIONEER DV-355
Operating instructions PIONEER DV-355
Instructions for use PIONEER DV-355
Instruction manual PIONEER DV-355



Your user manual
PIONEER DV-355

Manual abstract:

H017B_En This product is for general household purposes. Any failure due to use for other than household purposes (such as long-term use for business purposes in a restaurant or use in a car or ship) and which requires repair will be charged for even during the warranty period. K041_En [For Australian model] ENERGY STAR® and ENERGY STAR certification mark are registered US marks. K001B_En Information to User Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment. H011_En [For PX model] CAUTION: This product satisfies FCC regulations when shielded cables and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with electric appliances such as radios and televisions, use shielded cables and connectors for connections. H012_En This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation.

Reverse engineering or disassembly is prohibited. CAUTION · Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. · The use of optical instruments with this product will increase eye hazard. H013_En When disposing of used batteries, please comply with governmental regulations or environmental public instruction's rules that apply in your country or area. H048 En This product includes FontAvenue® fonts licenced by NEC corporation.

FontAvenue is a registered trademark of NEC Corporation. Contents Thank you for buying this Pioneer product. Please read through these operating instructions so you will know how to operate your model properly. After you have finished reading the instructions, put them away in a safe place for future reference. 01 Before You Start Features 6 What's in the box .

7 Putting the batteries in the remote control . 7 Using the remote control 7 Disc / Content Format Playback Compatibility 8 General Disc Compatibility 8 CD-R/RW Compatibility .8 DVD-R/RW Compatibility . 8 PC Created Disc Compatibility 8 Compressed Audio Compatibility . 9 Titles, chapters and tracks .9 DVD-Video regions 9 04 Getting Started Switching on 19 Let's Get Started .19 Using the on-screen displays . 21 Setting up with the Setup Navigator 21 Playing discs . 23 Basic playback controls 25 Front panel controls 25 DVD-Video disc menus . 25 Video CD/Super VCD PBC menus .

26 05 Playing Discs Introduction . 27 Using the Disc Navigator to browse the contents of a disc . 27 Scanning discs 28 Playing in slow motion 28 Frame advance/frame reverse . 29 Looping a section of a disc 29 Using repeat play 30 Using random play 31 Creating a program list 31 Editing a program list .33 Other functions available from the program menu 33 Searching a disc 34 Switching subtitles 35 Switching DVD audio language 35 Switching audio channel when playing a Video CD/Super VCD .35 Zooming the screen .35 02 Connecting Up Rear panel connections . 10 Easy connections 11 Using other types of video output 12 Connecting using an S-Video output 12 Connecting using the component video output 12 Taiwanese model only: Connecting using the D1 video output 13 Connecting to an AV receiver 13 03 Controls and Displays Front panel 15 Display . 16 Remote control 17 4 En Contents Switching camera angles 36 Displaying disc information 36 Setting/changing the Parental Lock level 45 Setting/changing the Country Code . 46 06 The Audio Settings Menu Audio DRC 37 Virtual Surround .

37 08 Additional Information Taking care of your player and discs 47 Handling discs . 47 Storing discs .47 Discs to avoid 47 Cleaning the pickup lens .48 Problems with condensation 48 Hints on installation 48 Moving the player 48 Power cord caution 48 Screen sizes and disc formats . 49 Widescreen TV users . 49 Standard TV users . 49 Resetting the player ..

Your user manual
PIONEER DV-355